



VF5633-00 Isolating Base

The VF5633 Isolating Base senses and detects short circuit faults on SLC loops.

- Up to 20 devices may be installed between isolating bases
- XPERT addressing



VF5605-00 Isolator

The VF5605 Isolator is placed at intervals on the loop and ensures that, in the case of a short circuit, only the section between the isolators will be affected. When the short circuit is removed, the isolators automatically restore power and data to the isolated section.

- Detects wiring short-circuits using patented technology
- Minimizes disruption from short-circuits
- Automatic de-isolation on short-circuit removal
- Up to 20 devices may be installed between isolators



VF5634-00 Isolator Base

The VF5634 Isolator Base is unique and designed to only accept the Isolator.

- Only accepts isolators